

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

Backflow preventer Scudo controlable and adjustable BA 580 to protect drinking water networks.

NF Certification with 10 years warranty.

With ball valves DN1/4".

To protect water networks up to category 4 (according to EN1717).



Size : DN1/2" to DN1"1/4

Connection : Male, male BSP

Min Temperature : +5°C

Max Temperature : +65°C

Max Pressure : 10 Bars

Specifications : Dezincification-resistant brass body **CR**
Controlable and adjustable (vertical or horizontal)
With male union

Materials : Dezincification-resistant brass body **CR** 4MS

*the installation defects and wear defects are not covered by the guarantee

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE


SPECIFICATIONS :

- Respect the flow direction indicated by an arrow on the body
- Horizontal or vertical position
- Male / Male BSP
- Controlable
- Low head loss
- With male union
- With ball valves 1/4" BSP
- 10 years manufacture warranty (the installation defects and wear defects are not covered by the guarantee)
- Simplified maintenance thanks to the removable cartridge
- Inspectable filter upstream and adjustable drain funnel

USE :

- Water distribution
- Min Temperature Ts : + 5°C
- Max Temperature Ts : + 65°C
- Max Pressure Ps : 10 bars

HEAD LOSS GRAPH :



BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

RANGE :




- Backflow preventer adjustable Male - Male BSP with fittings from DN 1/2" to DN 1"1/4 **Ref.955**



- Backflow preventer adjustable kit (with valves and strainer) from DN1/2" to DN1"1/4 **Ref.955014 to 955017**

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

OPERATING PRINCIPLE :




The backflow preventer consists of two check valves (1 and 2), an intermediate chamber known as "reduced pressure zone" (B) and of a discharge valve (3) connected to the latter. The water entering the backflow preventer opens the upstream check valve (1), presses against the membrane (4), which closes the discharge valve (3) by means of the self-contained cartridge (5), then finally the water opens the downstream check valve (2). In normal operating conditions the pressure in the intermediate chamber is always at least 14 kPa lower than the upstream pressure due to the effect of the first check valve setting.

This pressure difference Δp between the upstream zone (A) and the intermediate zone (B) ensures safety because, in the event of a fault, upstream pressure loss, back syphonage or downstream overpressure, opening (disconnection) of the discharge valve (3) occurs when the upstream pressure is still at least 14 kPa higher than the pressure in the intermediate zone, thus preventing all backflow of the downstream system medium towards the upstream system.

[Explanatory video](#)

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE


MATERIALS :



Item	Designation	Materials
1	Body	Brass CR dezincification-resistant CC770S-4MS according to EN 1982
2	Cartridge DN1/2"and 3/4"	CW724R-4MS Ecobrass® + PPSG40 + POM13
2	Cartridge DN1" and 1"1/4	POM 25
2	Diaphragm (fixed on cartridge)	EPDM
3	Ring	Brass CW617N-4MS according to EN 12165
4	Evacuation support	PP
5	Fittings	CW724R-4MS Ecobrass® according to EN 12164 and EN 12168
6	Circlip	EN 10088-2 (AISI 304)
7	Strainer	EN 10088-2 (AISI 304), mesh 0.47 mm and 0.4mm from DN1" to DN1"1/4
8	Valves	Brass CW617N-4MS according to EN 12165
9	Check valve	POM + NBR + AISI 302
10	Check valve ring	CW724R-4MS Ecobrass® according to EN 12164 + EPDM gasket

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE


SPARE PARTS :



		Ref.955004C	Ref.955004	Ref.955005	Ref.955006	Ref.955007
Item	DN	1/2"	1/2"	3/4"	1"	1"1/4"
2	Cartridge	Ref.9850170	Ref. 9850162		Ref. 9850166	
4	Evacuation support	-	Ref. 9850163		Ref. 9850167	
7	Strainer	-	Ref. 9850165		Ref. 9850168	
9	Check valve	-	Ref. 9850161		Ref. 9850169	

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE


COMPACT TYPE SIZE (in mm) :



DN	1/2"
L	146
L1	46
H	120
H1	61
Ø D	40
Weight (in Kg)	0.8
Ref. Sferaco	955004C
Code Caleffi	580004

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

SIZE (in mm) :




DN	1/2"	3/4"	1"	1"1/4
L	207.5	203.5	250	254
L1	68	66	100	102
L2*	137.5	137.5	161.5	161.5
H	145	145	209	209
H1	61.5	61.5	71.5	71.5
Ø D	40	40	40-60	40-60
Weight (in Kg)	1.5	1.5	2.6	2.7
Ref. Sferaco	955004	955005	955006	955007
Code Caleffi	580040	580050	580060	580070

L2* : Length without fittings


BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

SIZE COMPLETE KIT WITH VALVES AND STRAINER FOR HORIZONTAL POSITION :



Ref.	DN	L*	L1*	L2	L3*	H	H1
955014	1/2"	467	337	128	233	62	145
955015	3/4"	485	367	128	252	62	145
955016	1"	592	432	136	275	68	209
955017	1"1/4	649	472	136	303	68	209

SIZE COMPLETE KIT WITH VALVES AND STRAINER FOR VERTICAL POSITION :



Ref.	DN	L*	L1*	L2*	H	H1	H2
955014	1/2"	467	337	38	62	104	79.5
955015	3/4"	485	367	50	62	104	79.5
955016	1"	592	432	28.5	68	116	80
955017	1"1/4	649	472	40	68	116	80

*L, L1 et L2 as an indication because screwed assembly

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE**STANDARDS :**

- Manufacturer certified ISO 9001 : 2015 and ISO 14001 : 2015
- DIRECTIVE 2014/68/UE: Products excluded from directive (Article 1. § 2b)
- Protection for fluids up to category 4 according to **EN1717**
- Safety device according to **NF EN 12729**
- French water agreement **A.C.S. N° 20 ACC LY 563**
- Approval Belgian certificate **BELGAQUA N° 16/216/BA**
- Approval German certificate **DVGW N° NW-6305CQ0487**
- Approval English certificate **KIWA Regulation 4 (KUKreg4)**
- Safety device according to **NF045 doc 1 and 3**
- Threaded male BSP cylindrical ends according to **EN 10226-1**

ADVICE : Our opinion and our advice are not guaranteed and SFERACO shall not be liable for the consequences of damages.
The customer must check the right choice of the products with the real service conditions.

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

BACKFLOW :

Potable water fed from the mains supply may suffer from hazardous pollution caused mainly by contaminated fluids from plumbing systems flowing back directly into the mains supply. This phenomenon, termed "backflow" occurs when:


- a) the pressure in the mains system is less than that in the plumbing circuit receiving the supply (back syphonage). This situation may occur when there is a pipe breaking in the mains system or when demand on the mains supply from consumers is very heavy.
- b) the pressure in the plumbing circuit receiving the supply rises (back pressure) due, for example, to water being pumped from a well.



Risk assessment.

Given the potential dangers of the phenomenon and the requirements of current regulations, the risk of pollution from backflow must be assessed on the basis of the type of system and the characteristic of the fluid that flows in it. An appropriate backflow prevention device must be selected on the basis of that assessment performed by the system designer and the mains supplier. The device must be located along the supply line at those points at risk of backflow which would be hazardous to human health. The protection can be provided by inserting a backflow preventer at critical points in the circuit at the inlet from the mains supply or in the internal plumbing system. This will prevent polluted water from flowing back in all systems for which direct connection to the mains or an internal supply is considered hazardous.

Installation in a building with multiple outlets



Installation in a fire fighting system



BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

BACKFLOW PREVENTER USE, BA TYPE (According to EN 1717 and EN 12729) :

Use of backflow preventers (BA type) according to European standards EN 1717 and EN 12729

Proper use of the BA type backflow preventer is regulated by the new European standards on the prevention of pollution from backflow.

The relevant standard is *EN 1717: 2000 "Protection against pollution of potable water in water installations and general requirements of devices to prevent pollution by backflow"*.

The types of water contained in water systems are classified in this standard according to the degree of risk to health.

Category 1:

Water used for human consumption provided by a water company.

Category 2:

Fluid which does not present health hazard, as in category 1, whose quality has been compromised as a result in changes to its temperature, taste, odour or appearance.

Category 3:

Fluid which presents a slight health hazard due to concentrations of "low toxic" substances.

Category 4:

Fluid that presents a significant health hazard due to concentrations of "toxic substances".

Category 5:

Fluid that presents a serious health hazard due to concentrations of "pathogenic organisms, radioactive or very toxic substances".

Appropriate backflow prevention devices must be fitted in water supply systems on the basis of this classification.

Backflow preventers (BA type) can be used to protect against the risk of pollution from backflow for types of water up to category 4.

For category 5 types of water an air gap separation must be used.

The table on the right, entitled "Protection matrix", relates the categories of water to different types of system. It has been compiled on the basis of indications given by the European regulations.

The new European standard EN 12729 - *"Devices to prevent pollution by backflow of potable water. Controllable backflow preventer with reduced pressure zone. Family B - Type A"* - stipulate the functional, dimensional and mechanical requirements that must be met for controllable reduced pressure zone backflow preventers (BA type).

Protection matrix	
Type of system	Fluid cat.
	5 4
General	
Sprinkler fire fighting systems using anti freeze solutions	*
Industrial cisterns	*
Non-domestic hose union taps	*
Permeable hoses in others than domestic gardens, laid below or at ground level, with or without chemical additives	*
Primary circuits and central heating circuits in other than a house	*
Reclaimed water systems	*
Urinals, WC's and bidets	*
Domestic or residential gardens	
Mini-irrigation systems without fertilisers or insecticides applications, such as pop-up sprinklers or porous hoses	*
Food processing	
Bottle washing apparatus	*
Butchery and meat trade	*
Dairies	*
Food preparation	*
Slaughterhouse equipment	*
Vegetable washing	*
Medical	
Medical or dental equipment with submerged inlets	*
Bed-pans washers	*
Commercial clothes washing in health care premises	*
Domestic appliances such as sinks, baths and wash basins	*
Dialysing machines	*
Laboratories	*
Mortuary equipment	*
Catering	
Bottle washing apparatus	*
Dish washing machines in commercial buildings	*
Dish washing machines in health care premises	*
Drink vending machines in which ingredients or CO ₂ are injected into the supply or distribution pipe	*
Refrigerating equipment	*
Vegetable washing	*
Industrial and commercial applications	
Brewery and distillation	*
Car washing and degreasing plants	*
Commercial clothes washing plants	*
Drain cleaning plant	*
Dyeing equipment	*
Industrial and chemical plants	*
Industrial disinfection equipment	*
Laboratories	*
Mobile plant, tankers and gully emptiers	*
Printing and photographic equipment	*
Water storage for agricultural purposes	*
Animals drinking systems	*
Water treatment plant or water softeners using products other than salt	*
Pressurised water fire fighting systems	*
Water storage for fire fighting purposes	*
Agricultural	
Commercial irrigation with outlets below or at ground level and/or permeable pipes, with or without chemical additives	*
Commercial hydroponic systems	*
Insecticide of fertiliser applications	*


BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

INSTALLATION :

In line backflow preventer, must be installed by qualified personnel in accordance with current regulations. The backflow preventer must be installed with one shut-off valve upstream and one downstream (not included in the package). In compliance with EN 1717, the backflow preventer is equipped with an inspectable strainer located on the upstream connection of the body and easily accessible for maintenance purposes, and with an adjustable discharge tundish. The unit must be installed in an accessible position having dimensions such as to prevent it from becoming submerged due to accidental flooding (see installation diagram on page 8), and that is not at risk of freezing. The device should be installed horizontally, in accordance with the flow direction indicated by the arrow on the valve body. The device can also be installed on a vertical pipe with downward flow (top to bottom), in accordance with the flow direction shown by the arrow on the valve body. The EN 1717 discharge tundish must be oriented downward and connected to the sewer conveyance pipe. Rotation of the tundish can be locked by means of the two self-tapping screws supplied in the package. Before installing the backflow preventer flush the pipe with a high capacity flow rate. For highly dirty media, assess the opportunity of installing an additional inspectable strainer upstream.

CSTB installation guide :

<http://evaluation.cstb.fr/certifications-produits-services/produit/antipollution-des-installations-d-eau/>




Annual maintenance must be done once per year by a professional

<http://evaluation.cstb.fr/certifications-produits-services/produit/antipollution-des-installations-d-eau/>

If these operations are not done, the product can't be guaranteed.

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

INSTALLATION (SUITE) :



1	2	3	4	5
Stop valve (not included)	Strainer	Backflow preventer	Stop valve (not included)	Strainer (not included)

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE

Inspection and maintenance

The backflow preventer is a safety device and requires periodical inspection.

The first sign of poor functioning, generally caused by the presence of foreign bodies (sand or other impurities), is seen with a constant discharge from the discharge valve. This discharge is only a first alarm and does not mean in any way that the backflow preventer is not safe but the device and the strainer upstream from it requires dismantling and cleaning. A quick method of inspection (requires less than 15 minutes) is described in the table below.

N.B. If water is discharged from the discharge valve, a strong flow of water is recommended by turning on one or more taps since this is often sufficient to expel foreign bodies and return everything to normal.

Control instrumentation (code 575000)




The periodical (annual) control instrumentation consists of the following:

- Upstream pressure gauge
- Downstream pressure gauge
- Differential pressure gauge

The flexible tubes and necessary connections are included as well as accessories useful for dismantling the unit.
The instrumentation comes in its own case.

QUICK INSPECTION METHOD

Check that the system is under pressure before each operation and watch the discharge valve located on the lower part of the device (use a mirror if necessary).



N.B. : During normal operation there should be no constant discharge.
If there is a constant discharge dismantle and inspect the device.

BACKFLOW PREVENTER MALE TYPE BA 580 CONTROLABLE AND ADJUSTABLE REDUCED PRESSURE <u>INSTALLATION INSTRUCTIONS</u>

GENERAL GUIDELINES :

- Ensure that the check valves to be used are appropriate for the conditions of the installation (type of fluid, pressure and temperature).
- Be sure to have enough valves to be able to isolate the sections of piping as well as the appropriate equipment for maintenance and repair.
- Ensure that the valves to be installed are of correct strength to be able to support the capacity of their usage.

INSTALLATION INSTRUCTIONS :

- **Before installing the check valves, clean and remove any objects from the pipes** (in particular bits of sealing and metal) which could obstruct and block the valves.
- **Ensure that both connecting pipes either side of the check valve (upstream and downstream) are aligned (if they're not, the valves may not work correctly).**
- **Make sure that the two sections of the pipe (upstream and downstream) match, the check valve unit will not absorb any gaps. Any distortions in the pipes may affect the tightness of the connection, the working of the check valve and can even cause a rupture.** To be sure, place the kit in position to ensure the assembling will work.
- Before starting the fitting, ensure that the threads and tapping are clean.
- **If sections of piping do not have their final support in place, they should be temporarily fixed. This is to avoid unnecessary strain on the check valve.**
- The theoretical lengths given by ISO/R7 for the tapping are typically longer than required, the length of the thread should be limited, and **check that the end of the tube does not press right up to the head of the thread.**
- For the sealing assembly check valve piping, it is essential to use products that are compatible with the requirements of the French water agreement ACS : **plumbers hemp proscribed.**
- Make sure discharge connection is connected to the drainage network
- Respect installation dimension
- Complete standard installation notice (see page 12)